

Table of Contents

Handholes: Secondary Junction.....	RS-1
Handholes: 1/0 Cable Splice Enclosures	RS-3
Handhole: Tracer Wire	RS-10
Splice Box: 30" x 48" x 48"	RS-80
Splice Box: 30" x 48" x 20" (Maintenance Only).....	RS-80M
Regular or Intercept Box: 36" x 72" x 48" (Maintenance Only).....	RS-81
Pull Box: 30" x 84" x 48"	RS-82
Intercept Pull Box: 72" x 72" x 75"	RS-83
Intercept Splice Box: 30" x 48" x 48"	RS-84
Intercept Box: 36" x 84" x 48"	RS-85
Manhole: Feeder Cable Splice	RS-94
Manhole: Switch/Fuse Cabinet, 25kV.....	RS-96
Manhole: Switch/Fuse Cabinet, 12 or 25kV	RS-97
Manhole for Switch/Fuse Cab - Joint Customer.....	RS-97C
Manhole: Switch/Fuse Cabinet, 12 or 25kV (Maintenance Only).....	RS-97M
12kV Manhole Pad: Adjacent to Public R.O.W.	RS-98
12kV Manhole Pad: Not Adjacent to Public R.O.W.	RS-99
12kV Manhole Pad and Capacitor Pad: Adjacent to Public R.O.W.	RS-100
12kV Manhole Pad and Capacitor Pad: Not Adjacent to Public R.O.W.	RS-101
25kV Manhole Pad: Adjacent to Public R.O.W.	RS-110
25kV Manhole Pad: Not Adjacent to R.O.W.	RS-111
25kV Manhole Pad and Capacitor Pad: Adjacent to Public R.O.W.	RS-112
25kV Manhole Pad and Capacitor Pad: Not Adjacent to Public R.O.W.	RS-113
Manhole Pad for Switch, Fuse, Meter Cabinet.....	RS-116
Vault: Subsurface Switch.....	RS-117
Manhole: IntelliTEAM Switch.....	RS-118
Lid: Box and Vaults.....	RS-H

THIS PAGE INTENTIONALLY LEFT BLANK

				Electric Service Requirements	RSV-INX
				Table of Contents: Vaults and Boxes	
Drawn:	Eng:	Appr:	Date:		Revision: 4
JER	MP	-	07/22		Page 2 of 2